



QUALITY... PLAIN & SIMPLE®

### Throttle and Kickdown Cable Bracket for Edelbrock Pro-Flo XT Installation Instructions

#### General Installation Notes:

Please read these instructions completely before beginning the installation. If you have any questions please call.

Before beginning the installation, disconnect the negative battery cable and use wheel chocks to block the vehicle's wheels.

Make sure the engine, transmission, body and frame are properly grounded. We recommend using anti-seize lubricant on all aluminum threads.

This Bracket Kit is designed to be installed with a Lokar Throttle Cable and a Lokar Kickdown Kit (if applicable).

See **Fig. 1** for the component names.

**Step 1:** Remove the original Edelbrock throttle cable bracket from the intake manifold, if it had already been installed. Keep the original mounting bolts.

**Step 2:** Install the new Lokar Throttle Cable Mounting Bracket on the intake manifold in the same place as the original Edelbrock bracket, using the original bolts. **Fig. 2**

**Step 3:** If your throttle body pulley does not already have a provision for a Kickdown Cable and your application requires one, install the provided kickdown adapter using the two provided 1/4"-28 x 1/2" button head bolts with nylock jam nuts.

**Step 4:** The upper hole in the Throttle Cable Bracket is for the Throttle Cable, and the lower hole is for a Kickdown Cable. Install the Throttle and (if applicable) Kickdown Cables following the instructions that were provided with them. **Fig. 3**

# Throttle and Kickdown Cable Bracket for Edelbrock Pro-Flo XT Installation Instructions

Building American Quality... With A Lifetime Warranty!®

TOLL FREE 1-877-469-7440 • tech@lokar.com • www.lokar.com

